Product description

Explanation for 4 modesMode

```
  the tester outputs 1 pulse, whose pulse width is about 250ms□Mode
  the tester outputs 50 pulse, every pulse's pulse width is about 7ms□Mode
  the tester outputs 100 pulse, every pulse's pulse width is about
3.5ms□Mode
  the tester outputs pulse continuously at the rate of 50 pulses per about
1450ms, every pulse's pulse width is about 7ms□□
```

All-Sun EM276 Injector Tester Operation Instructions:

Turn off the vehicle's engineConnect Black / Red Clip to the Negative / Positive terminal of batteryConnect pulse output terminal to the fuel injector

Press the “MODE SET” key to select the desired pulse mode

Press the “PULSE” key, EM276 tester will output pulse to the injector, and then the pulse signal indicator will light as indication

All-Sun EM276 specification

```
  Power Supply: 12V vehicle battery□
  Operation Environment: 0 □ - 40□, relative humidity < 80%□
  Storage Environment: -10 □ - 50□, relative humidity < 85%□
  Size: 147x82x29mm (for main body only)□Weight: about 165g□
  Package Includes:□□1pc x Carriable Bag□1pc x Instruction Manual□
  1pc x Not Include Batteries
```

From:
https://kornequipped.com/mywiki/ - **KornEquipped WiKi**

Permanent link:
https://kornequipped.com/mywiki/doku.php?id=fuel_injection_tester

Last update: **2026/01/30 23:52**